





GDHRAD24FAN – RADIANT HEATER OPERATING INSTRUCTIONS



Please read these instructions carefully before use and retain this user manual for future reference.

I 、 Parts Description



- | | | | |
|-------------------|-----------------------|---------------------|-------------------|
| 1: Left enclosure | 2: Thermostat setting | 3: Quartz tube | |
| 4: Power switch | 5: Quartz tube | 6: Steel grill | 7: Heat reflector |
| 8: Left supporter | 9: Right enclosure | 10: Right supporter | |

II 、 Introduction

The GDHRAD24FAN radiant heater is an infrared heating device, with the aid of three long life Quartz halogen tube's to radiate heat evenly.

The GDHRAD24FAN is equipped with the below features

1. Halogen tube with heated thread enabling fast heat up times and efficient heating.
2. Heat reflectors to reflect heat away from the carpet.
3. Turbo fan for greater heat projection.
4. Tip over switch which cuts off electrical power, a safety measure in case of heating falling from upright position.
5. The unit is also equipped with a thermal cut off device which will switch off the power supply to the unit if any form of overheating is evident.

III、 Specifications

Rating voltage: 230-240V

Frequency: 50Hz

Rating power: 2400W

Gross Weight: 8.8KG

IV、 Safety Precautions

1. Only use the heater in 240 volt power outlet.
2. Do not position the appliance in close proximity to combustible materials such as furniture, curtains or bedding.
3. Always use the heater in an upright position and place it on a flat surface
4. Do not touch the protective grill or the back of the reflector while it is hot.
5. Do not cover the appliance during operation.
6. Do not operate the heater if you have damaged the heater or its components including the power lead. If the power supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person.
7. Do not attempt to repair the unit or disassemble it yourself as there are no user-serviceable parts.
8. It is not recommended to use an extension cord.
9. When the unit is not in use, please remove the plug from the power socket and store it in a safe dry area.
10. This product is not a toy. It should not be used by children or minors without supervision
11. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

V、 Operation

1. Plug the unit into a suitable electrical outlet, press top element on and the middle heating tube will be in use. The upper and lower heating tubes can be controlled by the corresponding switches. This will allow you to regulate the heat settings from 800W/ 1600W /2400W. For instance, you can either use 800W or 1600W by it self or combine the two to gain 2400W maximum heat output.
2. Press the fan indicator switch to operate the fan only or either with one of the above mentioned heat settings.
3. Note: Each switch is fitted with an LED light to indicate that it is ON.
4. When not in use, turn off power, remove plug from the wall and store the cord inside unit using the cable tidy compartment.

VI、 Maintenance

The regular cleaning of the reflector

- 1) Disconnect the unit from its power source. (Turn off unit and remove plug from the wall)
- 2) Take out the steel grill.
- 3) First use a damp cloth to wipe off dirt from surface of the reflector, and then clean with a wet cloth, finally clean it again with a dry cloth.
- 4) Once you have completed cleaning, fit the steel grill back on.
- 5) The unit's surface can be cleaned with a wet cloth. However, if you decide to use any detergents it is advised to use a non corrosive agent. (i.e. avoid petrol, thinner etc)

Glen Dimplex New Zealand Ltd
38 Harris Road, East Tamaki
Auckland, New Zealand
Phone: 09 274 8265
Fax: 09 274 8472
Email: sales@glendimplex.co.nz

Glen Dimplex Australia Pty Ltd
2/205 Abbots Road,
Dandenong South 3175
Victoria, Australia
Phone: 1300 556 816
Fax: 1300 058 900
Email: sales@glendimplex.com.au