



Setting Up Your New Masport ECS Remote Control

(Monaco ECS 2, Madrid ECS, Roma ECS, Grenada ECS, Newport ECS, Geneva ECS, Hampton ECS)

- **Install two AAA batteries (supplied) into the rear compartment of the remote**
- **Do not turn remote to on position**
- **Ensure mains power to your heater is turned on**
- **The following must proceed within thirty seconds of turning the power on to the heater**
- **Depress both lower buttons on the remote control simultaneously (Fan & Prog buttons), the letters LC will come up on the remote's LCD screen, hold buttons down for one minute. The fan will start automatically (except for Monaco ECS & Madrid ECS) and approximately one minute later the ignition sequence will begin, the heater will light.**
- **Should no gas be present the heater will not light, once ignition sequence stops depress the on-off button twice to restart the ignition sequence**
- **On the Roma, Grenada, Newport, Hampton and Direct Vent Geneva series the reset button or switch will require resetting as instructed in the owners manual. The reset button or switch is located behind the louvers on the Roma, Grenada & Newport fires and behind lower pedestal door on Geneva Direct Vent series.**
- **Should you try and use the remote control prior to carrying out above set up the heater will not respond to the remote control, repeat process**